

Installing Markins Captive Knob CK-1 for Quick Release Clamp



1. Remove your gear from the clamp.



2. Unscrew out the existing knob.



3. Remove the existing spacer. Wipe out the grease from the tip of the shaft.



4. Insert the new spacer. (Thick walled side faces the knob.) The new spacer is shorter than the old one in length.



5. Screw in and tighten the new knob.



6. Screw in and tighten the stopper.



7. Apply a small drop of superglue to the seam between the stopper and the shaft using a sharp object such as toothpick. This will prevent the stopper from loosening by vibration and usage.



8. (Review the previous procedures and make sure the knob is properly installed before closing the cap. The cap can't be removed without destroying it.) Push the cap into the knob. The cap is a permanent close.